



# Test X+Y+Z EndStops


[JellyBox HowTo: Test X+Y+Z EndStops](#)



In this video, we test that all the end stops are working properly.



Title: Testing the X Y Z End Stops



Manually place the Y and X axes centrally.

Be ready to turn the machine off if anything goes wrong!

Use the LCD display and select "Home X Y Z" from the menu.

If everything goes well, each axis should move to its home position and then stop.


Things that may go wrong:

The motor goes in the wrong direction – either flip the connector over, or reverse it in software.

The motor wanders – this is probably a bad signal. Check the connectors and the wires.

When plugging motor wires in or out, turn off the printer first! Else you may fry your drivers!


### Title: Check the Proximity Sensor



A simple check rules out the proximity sensor when troubleshooting.

There is a red LED on the underside of the sensor.

This LED will be on by default, and turns off when the sensor senses ferromagnetic metal. Put a knife or tweezers close to the sensor and see if the LED turns off. If it does, you know that proximity sensor hardware is fine.



If all else fails, take a nap. You'll feel better in the morning.