

#electro heatsinks

JellyBox HowTo: 24_Heat Sinks




In this video, we add heatsinks to the motor drivers to keep them cooler. The heatsinks are not needed for JellyBox operation, but they prolong the component drivers' life expectancy.


You'll need:



Small aluminum heat sinks (4) (The drivers are already on the RAMPS board.)

Title: Stick the Heatsinks onto the Drivers





Peel off the sticky backing on a heat sink.

Attach the heat sick onto a black driver chip making sure the ribs are horizontal. This way the heat can escape upward more efficiently. Repeat for all 4 driver chips.

This is optional but will increase the longevity of the printer. Drivers like to keep their cool.